



# Dreamcast VMU Teardown

This a complete teardown of the Dreamcast VMU (Virtual Memory Unit)

Written By: Caleb





## Step 1 — battery cover



- Remove the silver screw and batteries


## Step 2 — Rear shell



- Remove the four black screws
- ⚠ Be careful of the speaker wire
- Carefully peel the speaker away from the shell with a Spudger



### Step 3 — Battery terminals



- Remove the two battery terminal screws

### Step 4 — Motherboard



- Lift the main board from the shell
- Remove the screen from the motherboard
- Remove the screen stay, D-pad and rubber buttons from the shell
- And you're done!

To reassemble your device, follow these instructions in reverse order.

